

RED SEAL MEASUREMENT NEPTUNE OPERATING AND MAINTENANCE





RED SEAL
MEASUREMENT

Accu-Flo
Meter Service Ltd.

www.accuflo.com
1-800-921-ACCU



Operating and Maintenance For Petroleum Meters

M203

Rev. A

P.D. Oscillating Piston Flowmeters:

1 1/4" Type 4 Petroleum

1 1/2" Type 4 Petroleum



TABLE OF CONTENTS

Installation	1
Operation	3
Preset Models	3
Printer Register Models	4
Calibration	4
Register Maintenance	5
1½ Preset Models with Auto Stop Valve	6
1½ Preset Models with Auto Stop Valve	7
Measuring Chamber Maintenance	10
Gear Train Maintenance	12
Air Release Maintenance	12
General Maintenance	14
Troubleshooting	15




FIGURE 1
TRUCK INSTALLATION – PETROLEUM

CAUTION

CONTAINERS EMPLOYED TO COLLECT VAPOR OR LIQUID DISCHARGED FROM THE METER VAPOR RELEASE SHOULD BE OF SUFFICIENT SIZE TO PREVENT ANY LIQUID ESCAPE DURING NORMAL OPERATION, AND SHOULD HAVE A SUITABLE FLAME ARRESTOR VENT. ALL VENT LINES AND FITTINGS SHOULD BE OF METAL CONSTRUCTION, AND ALL VALVES SHOULD BE DESIGNED SO THAT NORMAL VIBRATION DOES NOT CAUSE ACCIDENTAL OPENING.

INSTALLATION

Use pipe thread cement on the outside of male threads only.

The flowmeter may be located at any convenient point on the discharge line from the pump. On Preset Models the base of the flowmeter casing is above the bottom of the valve. Do not clamp it in position without using the spacers provided or making a hole for the valve.

Be sure to allow room for the removal of the strainer basket, register, and air release mechanism. (See Figure 15.)

The piping on the outlet side of the flowmeter should be arranged so as to eliminate the possibility of draining the measuring chamber.

All piping connected to the flowmeter must be firmly secured to prevent strain on the flowmeter casing. The use of flexible connections to the pump or tank is recommended.

There must be no bypass connection around the flowmeter. Experience has shown that the valve in this line will eventually leak, work open or be accidentally left open.

In order to obtain a maximum rate of delivery, the compartment outlets and the piping should be as large as practical and the number of elbows should be reduced to a minimum. Sweep elbows should be used wherever possible.

Blowing The Hose: As it is impossible to blow all the liquid from the hose, the amount of liquid left in the lines on the discharge side of the flowmeter will not be the same before and after every delivery. It is therefore recommended that provision be made to keep the hose and outlet piping full of liquid at all times. For this purpose a hose nozzle with a check valve should be used.

Pumping Out Underground Tanks: In making provisions for pumping out underground tanks, DO NOT provide any connection between the outlet of the flowmeter and the compartments or manifold. A valve in this line which is leaky or carelessly left open will allow part of the metered liquid to be diverted.

Air Vent Line: The vent pipe from the air release should be $\frac{3}{4}$ " pipe or $\frac{1}{2}$ " inside diameter tubing. Care should be taken to prevent any possible obstruction to the free flow of air through this line.

It should either be connected to the top of one of the compartments or run into a container of about 5 gallons capacity to collect any liquid discharged with the air.

INSTALLATION

Piping

Interlocking of Compartment or Manifold Valves

If the valve of an empty compartment or auxiliary suction connection is open even slightly, while another compartment is being emptied, air drawn in through this valve will be churned up with the liquid to such an extent in the pump that some of it may be carried through the air release and cause over-registration on the flowmeter.

Either the compartment or the manifold valves should be interlocked so that delivery can be made from only one compartment at a time. Compartment valves are ordinarily interlocked by means of a selector lever in the can box.

Manifold valves may be of the 2-way 3-port lubricated plug type so arranged as to achieve the same purpose.




FIGURE 2
MANIFOLD VALVE INTERLOCKING

WARNING

When Installing

The connecting piping should be firmly secured to prevent strain on the flowmeter casing. Care should be taken that there is provision for expansion due to change in temperature.

All piping on the inlet side of the flowmeter should be very thoroughly cleaned out. Whenever possible, place a spool in the place of the flowmeter and flush out all lines thoroughly before the flowmeter is installed. **The majority of service calls on new installations would be eliminated if these directions were followed.**

Inlet and/or outlet are marked on flowmeter; do not install backwards.

After Installing

Pass sufficient liquid to clear the lines of air. Check the rate of flow. It should not exceed the rated capacity of the flowmeter. The bypass of the pump should be regulated to deliver the maximum practical rate of flow for the least amount of pressure. Pressure on the flowmeter should not exceed 125 psi. Do not try to increase the flow through undersized pipes and fittings by means of excessive pressures which will cause leaking gaskets and collapsed air release floats.

Temperature of the liquid should not exceed 140°F.

All flowmeters are tested and calibrated by Actaris Neptune and adjustment should not be necessary. If registration appears to be in error, the flowmeter registration should be checked using a calibrated volumetric prover. **The prover must be of sufficient capacity to permit a full flow delivery for at least one minute.** Do not base calibration upon assumed volume of ordinary containers or "dip stick" measurement.

If the registration is not in agreement refer to the section on "Flowmeter Calibration."

Cleaning The Strainer

While the installation is still new, the strainer, if used, should be cleaned very frequently. After the system has been thoroughly flushed of foreign material, only periodic maintenance of the unit is recommended.

Interlocking Of Compartment Or Manifold Valves

When Installing

After Installing

Cleaning The Strainer

OPERATION

To Operate The Flowmeter

1. Reset register to zero by turning operating knob to the rear stop. On Printer models, first insert ticket.
2. On Preset models, set the Preset wheels to the desired quantity.
3. Start pump — open Auto Stop valve (if used).
4. Open hose nozzle and make delivery.
5. After completing of delivery on Printer models, stamp final reading on ticket by turning operating knob to the front stop and remove ticket.

PRESET MODELS

To set the Preset mechanism press the setting buttons inward until the desired quantity is noted on the Preset wheels.

To Stop In Emergency

Pushing the red emergency stop button will trip the valve. After it has been used either the delivery may be completed automatically as originally set by reopening the valve or the mechanism may be set for a new figure. The accuracy of delivery in either case is not affected.

To Adjust Tripping Point

Registers are shipped from the factory with the Preset mechanism adjusted to trip correctly at the normal rates of flow. If, due to a change in the speed of closing of the valve or for other reasons, the Preset does not trip at the correct point, the trip point may be adjusted as follows:

If the valve is closing "off the mark," either late (over-delivery) or early (under-delivery), adjust the two connecting link nuts to bring the trip point to the zero mark. For right-hand assembly turn the nuts to lengthen the connecting link when the trip point is early, or turn to shorten if the trip point is late. For left-hand assemblies turn in the opposite direction. Continue this procedure until the final trip is on or close to the zero mark. On double trip valves, the intermediate flow rate will be satisfactory when the final trip is adjusted, as described.

Further adjustment of the trip point is possible, but is not recommended for normal applications. The following procedure should be used only when very exact settings of the final trip are necessary.

Adjust the connecting link nut as described above, and proceed as follows:

Remove the trip adjusting screw located in the lower right corner of the register front housing. Insert a narrow blade ($\frac{3}{16}$ ") screwdriver until it engages the slotted head of the adjusting screw. One turn of this screw will change the tripping point about one-quarter of one-tenth gallon.

If the Preset trips before reaching the zero mark (early), turn the adjusting screw clockwise.

If the Preset trips after reaching the zero mark (late), turn counterclockwise.

Do not turn the adjusting screw more than $1\frac{1}{2}$ turns in either direction from the initial position or pass a point where a resistance to further turning of the screw is felt.

If the trip point is not on zero after $1\frac{1}{2}$ turns, return the adjusting screw to its original position and turn the connecting link nut a half turn in the appropriate direction. Then repeat the trip screw adjustment procedure.

Gear shifter supplied as standard on 833 and 834 models. Optional on 831 and 832 models.

OPERATION

To Operate the Flowmeter

PRESET MODELS

To Stop In Emergency

To Adjust Tripping Point



FIGURE 3
PRESET 800 SERIES
PRINTER REGISTER

PRINTER REGISTER MODELS

To Insert and Remove Tickets

To insert a ticket be sure that the operating knob is turned forward to a stop. Then depress the dust bar and insert the ticket in the ticket slot under it, either "face down bottom end first" or "face up top end first," as noted on the instruction plate. Turn the operating knob backward to the stop. This resets the visible wheels to zero, locks the ticket in place and prints the initial reading on the ticket.

Upon completion of delivery, turn the operating knob forward to the stop. This operating prints the final reading and releases the ticket. It is now possible to remove the ticket.

To Adjust Ticket Guides

The Printer registers are shipped from the factory with the ticket guides adjusted for a standard (4 $\frac{1}{8}$) width ticket. If for any reason it is necessary to reposition the ticket, proceed as follows:

1. Remove top cover.
2. Insert a ticket into the printer. Loosen the clamp screws on the rear of the ticket guides. Move the guides to the right or left as required. Tighten clamp screws. The ticket must slide freely between the guides. If the ticket bends at the forward end of the guide, remove the guide and rebend the tail of the guide.
3. If it is necessary to raise or lower the printing, push the two stop pins to the front or rear with the end of a screwdriver.
4. Replace the top cover and reseal.




FIGURE 4
PRINT UNIT ADJUSTMENTS

To Change Setting of "Letter Wheels

1. With the top plate removed, the "letter" wheels are visible (see Figure 4).
2. By means of a screwdriver or similar tool, turn the wheels until the desired letters appear at the top where they are in position to print.

To Change Position Of The Register (Non-Preset Models)

Remove the register from the flowmeter. Two studs and two threaded holes will be seen on the flowmeter cover. Turn register 180° and tighten the screws in front of the register. For convenience the operating knob may be moved to the opposite side of the register. If the register is to be turned 90° transfer the studs to the two empty holes.

Gear shifter standard on 833 and 834 models. Optional (extra charge) on models 831 and 832.

CALIBRATION

Test all flowmeters with 50-gallon or larger test measures. Do not base calibration upon truck compartments.

Preset flowmeters should first be tested and adjusted without the Preset (set the register for more than the test quantity), then tested with the Preset. If the Preset mechanism does not trip correctly, see instructions on page 3 "To Adjust the Tripping Point." Rerun the test, and then if the delivery is not correct, a service man should be called.

PRINTER REGISTER MODELS

To Insert and Remove Tickets

To Adjust Ticket Guides

To Change Setting of "Letter" Wheels

To Change Position of the Register (Non-Preset Models)

CALIBRATION

Erratic Registration

Erratic registration is an indication of trouble in the system caused by air or dirt in the measuring chamber. Do not try to correct this by recalibration of the flowmeter, but first check over the piping for air leaks, clean the strainer and then, if the trouble has not been found, clean the flowmeter as directed on pages 10 and 11. If this does not correct the trouble, check for faulty installation.

Over-registration is an indication of air, whereas under-registration is generally caused by dirt or pipe scale in the measuring chamber, or the liquid bypassing the flowmeter in some manner.

Consistent Over or Under-Registration

When the flowmeter registers consistently either more or less than is delivered, the calibration may be corrected in the following manner:

1. Remove four screws holding top cover and remove cover.
2. Lift and turn the change gear shifter (see Figure 5) in the direction indicated on the top of the shifter.
3. There is a series of holes, marked A to H, in the plate into which the guide pin enters at different settings. Altering the setting by one hole changes the calibration approximately 17 cubic inches in 50 gallons.

Example: Suppose the flowmeter consistently gives 34 cubic inches too much when it registers 50 gallons. After removing the cover plate move the gear shifter 2 spaces to the right (*from position E to position C*) to decrease the delivery about 34 cubic inches in 50 gallons.

After changing the calibration always replace top cover, making sure that the sheet steel housing on the sides and back fits into the groove in the bottom edge of cover. Run a small amount of liquid through the flowmeter before testing. To prevent tampering, always reseal after calibration.

Note: For broader change gear requirements, refer to form TSG-310.




FIGURE 5
GEAR SHIFTER ADJUSTMENTS

REGISTER MAINTENANCE

Register parts are such that only minor field repairs are advisable. When a register is in need of repair or service other than that for which instruction is given here, it should be returned to an authorized Actaris Neptune distributor for service.

To Remove Register From Flowmeter

Loosen the two clamp screws on lower front of the register. Lift the register off. On Preset Models the valve linkage must first be disconnected. (Remove cotter pin and washer at valve end.)




FIGURE 6
CHANGE GEAR ARRANGEMENT

When one register is removed and another substituted, (1) Check the number of teeth on the change gears (see Figure 6). They must be the same as the gears on the old register **and on the same respective spindles**. The number of teeth is stamped on each gear. To remove these gears, close the split end of the spindle with a pair of pliers and pull off the gear. After putting on a gear, spread the end of the spindle slightly. (2) Make sure the position of the "Gear Shifter" is the same on the new register as on the old one — each hole is lettered for convenience.

To Clean Register Mask

The Register mask is made of plastic and requires special treatment. Instructions for cleaning are given on next page:

Erratic Registration

Consistent Over or Under-Registration

REGISTER MAINTENANCE

To Remove Register From Flowmeter

To Clean Register Mask

If the mask becomes soiled with grease and oil, solvents for these substances, such as kerosene or naptha, may be used to remove dirt. However, sprays that are commonly employed in cleaning glass windshields must not be used as cleaners, since they contain solvents.

A water solution of nonabrasive soap is recommended for washing grease, oil, or dirt from the mask. It is then cleansed by rubbing gently with a soft cloth, in a manner similar to cleaning window glass, rinsing the plastic in clean water, and finally drying.

Scouring cleanser and similar material must not be used in cleaning the mask, since they contain abrasives that scratch the surface.

The use of solvents, such as acetone, ethyl acetate, benzene, and ethylene dichloride to brighten the surface is never recommended since these substances soften the surface of the plastic.

1 1/4" PRESET MODELS WITH AUTO STOP VALVE

To Rotate Register

When the flowmeter is assembled as a Left Hand assembly and it is desired to change it to a Right Hand assembly, or vice versa, proceed as follows:

1. Remove cotter pins (E) from valve linkage.
2. Unscrew the outside register link lock nut (P) and remove connecting rod (G).
3. Remove register link (N), rotate 1/2 turn and reassemble onto register as described in appropriate valve adjustment instructions.
4. Loosen two clamp screws on lower front of register, lift register up and turn register 180°.
5. Remove four handle housing assembly hex screws (C) and remove handle housing assembly from valve.
6. Remove valve handle set screw (B) and slide handle off bushing. Remove two cam retaining screws (*not shown*). Remove shaft seal plug (D). Disassemble valve operating shaft and valve operating cam. Reassemble valve operating shaft and install valve operating cam in the reverse direction. Reinstall two cam retaining screws and shaft seal plug. Reinstall housing assembly with valve operating cam acting on pilot rod. Secure with four hex screws (C). Reassemble valve handle (A) on knurled knob in position as shown for specific assembly.

After completing the above instructions, the valve linkage must be adjusted in accordance with the procedure for the specific type valve as outlined on the following pages.

1 1/4" PRESET MODEL WITH AUTO-STOP VALVE

To Rotate Register




FIGURE 7
VIEW LOOKING AT BACK OF REGISTER

To Adjust Linkage Valve

Note: Before any adjustment of the Auto-Stop Valve is made, be sure that the Auto-Stop setting wheels indicate a quantity other than zero to ensure that the trip mechanism of the register is in proper position.

1. Depress the emergency stop button on the register and turn the shaft (O) clockwise (*as viewed from rear of register*).
2. Assemble register arm (N) on knurled knob in position as shown for specific assembly. (*See Fig. 7*). Arm should move an equal distance each side of vertical center line (M) (Angle x=x).
3. Assemble one nut (P) on connecting rod (G) and the other end of the connecting rod to the center hole in handle (A) using washers and cotter pins (E).
4. Open valve all the way. Turn shaft (O) counter clockwise to latch up mechanism. With valve held open tighten nut (P) against register arm link. Then assemble and tighten second nut at (P).
5. Depress the emergency stop button and allow the valve to close. At this point the leakage between the valve and the register must be free. If it is not, the above adjustments must be rechecked.
6. Set the register to deliver the minimum quantity and open the valve to run product through the flowmeter.
7. After the initial trip occurs the valve should close to the intermediate flow position. This rate will vary depending on product metered. If the valve closes too far, or all the way, adjust nuts (P) to provide additional rod length.
8. It is sometimes necessary to change the position of the handle. This can be done by loosening handle screw (B) and repositioning the handle as follows: if the register mechanism will not latch up, position the handle further toward the register. If the valve will not close, the handle may be positioned away from the register. Fine adjustments may be made by changing the effective length of connecting rod (G) utilizing nuts (P). Effective length of connecting rod (G) may also be varied by positioning the end of the rod in the upper or lower holes in the valve handle.
9. The Auto-Stop trip adjusting screw should be near its mid-position.

To Adjust The Tripping Point

The flowmeter is shipped from the factory with Auto-Stop mechanism adjusted to trip correctly at maximum rates of flow while the flowmeter is measuring a non-viscous liquid. Trip adjustment after final installation may be necessary due to differing flow rate and/or viscosity.

If the Auto-Stop does not trip off at the correct mark due to a change in the speed of closing of the valve, different rates of flow, or any other reason, the adjustment is made as follows:

Remove the screw located in the lower right corner of the front housing. Insert a medium-sized screwdriver into this hole until it engages the slotted head of an adjusting screw. One turn of this screw will change the tripping point about one-quarter of one graduation of the first wheel.

If the Auto-Stop trips before reaching the zero mark, turn the adjusting screw in a clockwise direction.

If the Auto-Stop trips after the zero mark, turn the adjusting screw in a counterclockwise direction.

1½" Preset Model With Double Trip Valve

To Rotate Register

When the flowmeter is assembled as a left-hand assembly and it is desired to change it to a right-hand assembly, or vice versa, proceed as follows:

To Adjust Linkage Valve

To Adjust The Tripping Point

1½" PRESET MODEL WITH DOUBLE TRIP VALVE To Rotate Register

1. Remove clevis pin (E) from valve linkage.
2. Unscrew the outside register link lock nut (P) and remove connecting rod (G) and clevis (F) as a unit.
3. Remove register link (N), rotate 1/2 turn and reassemble onto register as described in appropriate valve adjustment instructions.
4. Loosen two clamp screws on lower front of register, lift register up and turn register 180°.
5. Remove operating shaft cap screw (C) on both sides.
6. Interchange connecting rod arm (H) and valve operating handle (A). The connecting rod arm must be assembled with notches (J and K) in specific relationship. (See item 3 of valve adjustment instructions for details regarding position of notches.)
7. Reassemble operating shaft cap screws (C).
8. Remove valve handle stop set screw (B) and screw into hole on opposite side of valve.




FIGURE 8
VIEW LOOKING AT BACK OF REGISTER

After completing the above instructions, the valve linkage must be adjusted in accordance with the following procedure:

Adjustment Of Auto-Stop Valve

Before any adjustment of the valve is made, be sure that the Preset setting wheels indicate a quantity other than zero to insure that the trip mechanism of the register is in proper position.

To Adjust Valve Linkage

1. Depress the emergency stop button on the register and turn the shaft (O) clockwise.
2. Assemble register arm (N) on knurled knob in position as shown for specific assembly. (See Fig. 8). Arm should move an equal distance each side of vertical center line (M) (Angle x = x).
3. Assemble valve arm (H) as shown for specific assembly. On the right hand assembly there must be one notch between the cast mark (K) on the valve arm and the cast mark (J) on the stop plate (J above K). On the left hand assembly these cast marks must be in line.
4. Assemble one nut (P) on connecting rod (G) and assemble clevis to the other end of the connecting rod a distance of 1".
5. Insert end of connecting rod through register arm link and assemble clevis (F) to valve arm (H) using upper hole. (See Figure 8). Insert clevis pin (E).
6. Open valve all the way. The opening of the valve is stopped by the set screw (B) which should project approximately $\frac{1}{8}$ " below the lug holding it. Turn shaft (O) counterclockwise to latch up mechanism. With valve held open, tighten nut (P) against register arm link. Then assemble and tighten second nut at (P).
7. Depress the emergency stop button and allow the valve to close. At this point the linkage between the valve and the register must be free. If it is not, the above adjustments must be rechecked.

Adjustment of Auto-Stop Valve

To Adjust Valve Linkage

8. Set the register to deliver the minimum quantity and open the valve to run product through the flowmeter.
9. After the initial trip occurs the valve should close to the intermediate flow position. This rate should be approximately 15 to 20 gpm. If the valve closes too far, or all the way, unscrew clevis (F) on rod (G) to hold valve open further. If the rate of flow is too fast during the intermediate position, turn the clevis onto the rod to allow the valve to close further. It should not be necessary to turn more than one turn in either direction.
10. It is sometimes necessary to change the position of set screw (B) if the clevis has been readjusted. If the register mechanism will not latch up, unscrew the set screw to allow the valve to open further. If the connection rod (G) is under compression, when the valve is held all the way open, turn the set screw down to relieve the pressure on the register.
11. The Auto-Stop trip adjusting screw should be near its mid-position. If a small adjustment of this screw will not permit the register to shut off "on the mark" it is usually possible to correct this by a slight adjustment of the clevis (F). This will move the main valve nearer to or further away from its seat during the intermediate flow and thereby change the amount of time needed for the valve to fully close at the last trip (Also see To Adjust The Tripping Point.)

NOTE: If it is difficult to obtain proper rate of flow during intermediate trip position and still have regular latch up fully. Check Auto-Stop valve to insure that it is opening all the way. Check valve by removing set screw (B) and clevis (F) from valve arm; open valve as far as possible. The distance between lug on arm and lug on stop plate must not be more than $\frac{1}{4}$ ".

DOUBLE TRIP MAINTENANCE

To Disassemble and Assemble Double Trip Valve

1. Remove valve from flowmeter.
2. Remove two screws (A) holding retaining ring (B) at inlet of valve. (Caution: End plate should be held by hand when removing screws because of spring tension beneath the plate.) All internal parts of the valve can now be removed with the exception of the operating shaft mechanism. The removal of the internal parts from the valve body may be assisted by operating the valve handle as when operating the valve.
3. Disassemble piston and throttling ring assembly (items F to K). Inspect valve seats, "O" ring gaskets, piston ring (D), and cylinder (C) for damaged surfaces. Replace all defective parts with new parts.
4. Reassemble piston and throttling ring assembly. Apply Loctite Black Max 380 to bond the disc (G) to the piston (F), and allow 24 hours to cure before placing in service. Apply Loctite Threadlocker 242 under heads of three piston assembly screws (H).
5. Assemble pilot valve (E) on pilot valve rod (J). Place assembly into valve body.
6. Place one end of spring over pilot valve boss.
7. Place other end of spring over boss in cylinder (C) and press cylinder down over piston (F). Back of cylinders should be below flange face for proper assembly.
8. Hold cylinder in place, place "O" ring in body recess and attach retaining ring (B) with two screws (A).
9. Open valve as far as possible — make sure that valve is not being stopped by set screw (L).

DOUBLE TRIP MAINTENANCE

To Disassemble and Assemble Double Trip Valve




FIGURE 9
VALVE ASSEMBLY

To Adjust Rate of Closing Of Valve

Variations in the viscosity of the liquids being measured will cause changes in the rate of closing of the valve from its full open position to its intermediate position. (Valve should reach its intermediate position with approximately 4 gallons remaining on Preset setting wheels.)

Setting of orifice plate is indicated on tag attached to valve.

The rate of closing can be adjusted by changing the position of orifice plate which is readily accessible through inlet of valve. (Valve does not have to be disassembled.)

(Figure 10) View of valve inlet showing position of orifice plate for gasoline and other low viscosity liquids. Note that orifice opening is completely covered. (Photo shows 1½" valve.)

The normal position of orifice plate in valve to be used with gasoline or other low viscosity liquids will be set with orifice opening covered. If valve closes too slowly with this setting, turn plate counterclockwise to expose either small, medium or large hole as required.

To Inspect Operating Shaft Seals of Preset Valve

The following steps should be followed if it becomes necessary to disassemble the operating shafts because of leakage. Shaft seal cannot be corrected by tightening of the bearing bracket screws. In this case new "O" rings are usually required. (See parts list for 2" Type 1A Double Trip Preset Valve.)

1. Remove the valve handle (A), connecting rod arm (I), two stop plates (B and H), and two roll pins (C). Remove eight screws and pry off two shaft bearing brackets (D). Do not damage gaskets (G).
2. The two "O" ring seals (E) can be inspected for damaged surfaces. Replace any defective "O" rings.
3. To remove the operating shaft (J) and two shaft bearings (D), first remove the two screws in the valve operating cam (K). Inspect the shaft for score marks and replace if necessary. New "O" ring seals are worthless if used with a badly scored shaft.
4. Remove retainer (F), replace "O" rings (G) and reinstall shaft bearings (D).
5. Reassemble the operating shaft and cam.
6. Replace rings, flat gaskets, two roll pins, two stop plates, connecting rod arm and valve handle.

MEASURING CHAMBER MAINTENANCE

To Remove and Disassemble

This operation is not difficult and may be performed by any competent mechanic. No special tools are required. No trouble need be expected, if these few simple, but important, directions are followed. Do not open the flowmeter until you have checked over all other possible causes of erratic registration.

To Adjust Rate of Closing of Valve




FIGURE 10
VALVE ORIFICE PLATE

To Inspect Operating Shaft Seals of Preset Valves




FIGURE 11
SHAFT ASSEMBLY

MEASURING CHAMBER MAINTENANCE

To Remove And Disassemble

1. Prepare a clean surface on which to place the parts as they are removed. The parts are machined to close tolerances and should be handled with care. Have a replacement gasket ready before opening the flowmeter.
2. Loosen the two clamp screws on the lower front of the register. Lift the register off. On Preset Models the valve linkage must first be disconnected. (Remove cotter pin and washer at valve end.)
3. Remove the flowmeter cover taking care not to damage the gasket.
4. Lift the measuring chamber from the flowmeter casing.
5. Remove the upper cylinder head by inserting a screwdriver in one of the slots provided and prying it off. Be careful not to scratch or nick any part of the chamber.
6. Lift out the piston by its spindle. If care is taken to draw it straight, it should come out easily. Do not force it.
7. Remove the control roller and the diaphragm from the lower cylinder head.
8. The seal pin may be removed (for replacement only) by pulling upward, using pliers if necessary.

To Clean The Measuring Chamber

The parts may be most easily cleaned of scale, etc., by means of a good, coarse, stiff bristle (not wire) brush and gasoline. All foreign matter, except deeply embedded chips or heavy corrosion due to water, may be removed in this manner. Do not use abrasives, such as emery cloth or sandpaper. When the piston is badly corroded, the whole chamber should be replaced.



FIGURE 12
MEASURING CHAMBER COMPONENTS

The parts of the measuring chamber which may show wear after long periods of service are the diaphragm and the control roller. These parts will not require replacement until the accuracy begins to fall off at low rates of flow. To change these parts, merely substitute the new for the old when the flowmeter has been taken down for cleaning.

Experience has shown that the sliding surfaces between the chamber and piston take on a burnished finish and wear little if any.

To Reassemble The Chamber In The Flowmeter

Before reassembling the flowmeter, rinse all parts in gasoline. If possible, flush out the flowmeter body. Assemble the parts carefully; they should slide together easily without hammering or forcing. It is essential that all contact surfaces between the cover and chamber, or between the measuring chamber and its seat in the casing, be clean and free from nicks.




FIGURE 13
CHECKING THE
PISTON MOVEMENT

To Clean The Measuring Chamber

To Reassemble The Chamber In The Flowmeter

1. Assemble diaphragm and seal pin in chamber if replacement was necessary.
2. Place the control roller on its pin and see that it will rotate freely.
3. Replace the piston and oscillate it carefully by hand; it should move easily without binding. If it sticks, do not force it, but remove and locate the cause. Do not file down the roller as this will impair the accuracy of the flowmeter.
4. Replace the upper cylinder head and again oscillate the piston to make sure that is free.
5. When replacing the measuring chamber in the casing, be sure that the seat is clean and free from nicks. *Make sure the dowel pin in the main casing enters the slot in the chamber bottom properly and allows the chamber to rest on its seat.*
6. Before replacing the cover, first be sure the chamber is properly seated and inspect the gasket. Then set the arm of the gear train so that it will not come down on the piston spindle.
7. Make sure the cover is down on its seat before tightening the bolts.

GEAR TRAIN MAINTENANCE

To Repair Leaking "U" Cup Seal Stuffing Box

Keep dirt out of register and avoid injury to gasket.

Remove the register. If tightening the stuffing box nut with the fingers does not stop this leak, replace "U" cup shaft seal. It may also be necessary to replace "U" cup shaft seal and to replace the gear train.

1. Remove the register.
2. Remove the star connection (1), using a No. 8 Allen wrench.
3. Unscrew the stuffing box nut (2).
4. Remove shaft seal (3). Inspect upper end of spindle to be sure it is free of nicks or burrs which might damage the new shaft seal when it is placed on spindle. Remove the clamp nut (6); gear train assembly can be removed from underside of flowmeter cover.
5. Replace shaft seal with new part. Be sure expander (4) and spring (5) are in position before inserting new seal.
6. Assemble nut and tighten down all the way.

To Replace The Gear Train

1. Remove the register (see page 5).
2. Remove the star connection (1), using a No. 8 Allen wrench.
3. Remove the flowmeter cover, with gear train assembly attached. Keep dirt out of flowmeter and avoid injury to the cover gasket.
4. Unscrew the stuffing box nut (2).
5. Remove clamp nut (6); gear train assembly can be removed from underside of flowmeter cover.

AIR RELEASE MAINTENANCE

General Note — "O" Ring Gaskets

1. The groove in which the "O" ring is located must be free of dirt.




FIGURE 14
GEAR TRAIN ASSEMBLY

GEAR TRAIN MAINTENANCE

To Repair Leaking "U" Cup Seal Stuffing Box

To Replace The Gear Train

AIR RELEASE MAINTENANCE

General Note – "O" Ring Gaskets

2. The flat face against which the "O" ring seats must be clean and free of nicks or dents which will allow the pressure to leak between the gasket and the metal.

To Clean The Strainer

Remove the strainer cover and pull out the screen. Blow the dirt off screen with compressed air and rinse in gasoline or kerosene.




FIGURE 15
AIR RELEASE COMPONENTS

Air Release Valve Troubles

Troubles with this unit may arise from:

- a) Collapsed ball float allowing vent to remain open.
- b) Dirty or worn valve seat.
- c) Improper position of float.
- d) Sticking back pressure valve.

To Inspect Air Release Unit

1. Remove the Strainer (see Fig. 15).
2. Uncouple the Vent Connection.
3. Remove the cap screws on the air release cover and lift out the mechanism.
4. If the float is damaged, remove by taking out the hinge pins and replace with a new one.
5. If the valve is leaky,
 - a. Remove the air release unit from the underside of the cover by unscrewing three small screws.
 - b. Take off the sleeve with piston seal.
 - c. Move the ball in the direction of the valve housing as far as possible and remove valve disc assembly.
 - d. Inspect piston seal for any obvious deterioration.
 - e. The valve disc assembly should be taken apart to inspect for dirt or defective pilot valve seat. A pair of fine nose pliers is needed for this. Replace valve if seats are defective.
 - f. When reassembling, make sure the piston seal is properly positioned and that the valve disc assembly moves freely in sleeve.
6. To avoid possible mechanical interference, the support bracket and float linkage should appear as shown above. If this is not as shown, the framework has been bent out of shape. To adjust, bend metals back in the direction required.

To Clean The Strainer

Air Release Valve Troubles

To Inspect Air Release Unit

To Remove Back Pressure Valve

1. Remove Air Release and Strainer from the line by unbolting at inlet flange and flowmeter inlet.
2. Remove strainer sleeves and air release valve.
3. Remove drain plug.
4. Hold block of wood (1 $\frac{3}{4}$ " diam.) against back pressure valve and knock valve out of housing by means of 1/2" diameter rod inserted through drain plug hole.



FIGURE 16
BACK PRESSURE
VALVE

GENERAL MAINTENANCE

In the maintenance of the accuracy of Actaris Neptune Flowmeters, little is necessary other than to see that the proper conditions of operation are preserved. These conditions, once the flowmeter has been properly installed, consist merely in guarding against foreign matter, such as air, sediment and water, entering the measuring chamber.

The liquid passing through the measuring chamber must be free of grit and other forms of sediment in order to prevent unnecessary friction and the scoring of the piston and chamber walls. Evidence of trouble from this source is under-registration of the flowmeter.

Periodic cleaning of the strainer at the inlet of the flowmeter will help to insure against this trouble. In the design of this unit, particular care has been taken to make this operation as simple as possible. See page 13.

Being an instrument which measures by volume, a flowmeter will record the passage of air as well as the liquid being measured. Over-registration is the result. The air release valve is intended to prevent this condition by venting this air before it passes through the measuring chamber.

Incidental water will cause no damage to the flowmeter. Trouble from this source may be expected only when water is allowed to stand in the flowmeter for considerable periods of time.

When washing trucks, care should be taken to cover the register. Water in the register will cause trouble particularly in cold weather when ice may form and cause sticking.

Test with 50-gallon or larger test measures. Do not base calibration upon truck compartments or on 5-gallon measures. Instructions for calibration will be found on page 5.

Preset Flowmeters should first be tested and adjusted without the Preset (set the register for more than the test quantity); then test with the Preset. If the Preset mechanism does not trip correctly see instructions on "To Adjust the Tripping Point," page 3.

Before a flowmeter is put in storage the measuring chamber must be flushed with a light lubricating oil to prevent condensation damage.

To Remove Back Pressure Valve

GENERAL MAINTENANCE

Sediment

Air

Water

Testing

Storage

TROUBLESHOOTING






TROUBLESHOOTING

- 1. Register Not Working When Liquid is Flowing**
 - a) Bypass around flowmeter not shut off.
 - b) Frozen condensation inside register.
 - c) Register in need of repair.
 - d) Sheared key on "Change Gear" — caused by ice in register.
- 2. Leakage at the Stuffing Box**
 - Loose stuffing box nut or worn spindle.
- 3. Chronic Leakage at the Main Case Gasket**
 - a) Excessive line or shock pressure.
 - b) Broken gasket or loose bolts.
- 4. Reduction in the Rate or Complete Stoppage of Discharge**
 - a) Pump bypass stuck open.
 - b) Air release valve fails to close allowing the liquid to escape through air vent.
 - c) An open valve in the piping allowing liquid to circulate around the pump.
 - d) Worn pump.
 - e) Blocked strainer due to sediment or frost.
 - f) Piston in flowmeter stuck, caused by dirt. Check strainer and clean measuring chamber.
- 5. Over-Registration — Erratic**
 - a) Leaking valve in empty compartment causing an emulsion of air and oil.
 - b) Air release valve jamming allowing air to pass through the flowmeter
 - c) Spring in back pressure valve broken or valve stuck open.
 - d) Vent line from the air release valve plugged causing air to pass through the flowmeter.
 - e) Leaks in the suction line such as at valve stems, pump packing, or flange gaskets.
 - f) Air pockets in closed-end piping in the suction line.
 - g) Manifold or compartment valves only partly open causing excessive suction.
 - h) Suction piping too small causing excessive suction.
- 6. Under-Registration — Erratic**
 - a) Dirt in the measuring chamber.
 - b) Badly worn control roller or diaphragm.
 - c) Main casing distorted or damaged.
 - d) Dirt under the seat of the measuring chamber at the outlet port (after cleaning).
 - e) Leakage around the flowmeter due to partly open valve.
- 7. Consistent Over- or Under-Registration**
 - Flowmeter in need of calibration.
- 8. Liquid Leaking Out the Air Release Vent**
 - a) Improper operation.
 - b) Worn, damaged or defective valve unit.
- 9. Printing Not Clear in Cold Weather**
 - Ticket carbon not suitable for cold weather use.
- 10. Cut Off is Not Accurate**
 - Trip Adjustment


PRESET MODELS

- 10. Cut Off is Not Accurate**
 - Trip Adjustment

1 1/4" TYPE 4 WITH 1" A/S VALVE 800 SERIES REGISTER



1½" TYPE 4 WITH 2" A/S VALVE 800 SERIES REGISTER



Accu-Flo
Meter Service Ltd.



4028 - 7th Street S.E., Calgary Alberta T2G 2Y8
Phone: (403) 243-1425 Fax: (403) 243-6577
Toll Free: 1-800-921-ACCU(2228), sales@accuflo.com



U.S.A./International
1310 Emerald Road
Greenwood, SC 29646-9558
Tel.: Toll-Free (800) 833-3357
(864) 223-1212
Fax: (864) 223-0341

Specifications subject to change without prior notification.



RED SEAL
MEASUREMENT